

Doorpac fact sheet 1. Quick2Fit Installation guide.



Important: Do not remove the shipping brackets or bearers until stage 3.

Quick2Fit

1. Slot the doorset into the aperture. Ensure the doorset is placed centrally and levelled by placing a spirit level on the doorset head - pack under each jamb as required. The doorset is designed for a 15mm carpet gap, this can be adjusted by trimming or packing each jamb.

2. Fix the doorset in position using 40mm screws in the eight metal stretcher plates. Ensure the doorset is level by placing a spirit level against the jamb and hinges. Pack behind the brackets if required.

3. The frame should now be secure. Remove the shipping brackets and open the door to secure the lining internally using the traditional method of screw and packing.

4. Using suitable screws, screw through the jamb into the wall ensuring 50mm of the screw is secure in the wall. Pack between the wall and lining as necessary to keep the lining level.

5. Using a quality adhesive or pinning, fit the door stops into position. The stops also hide the frame fixings.

6. Join the architrave components using the clips provided. Drop a small amount of pva into the joint to help secure the mitre.

7. Apply a quality adhesive along the architrave groove in the frame.

8. Slot the architrave set into the groove on the frame and push the architrave firmly into the slot, take care not to break the mitre joint.

9. Door installation is complete. If the ironmongery option has been chosen, no more work is required.

Installation of Fire Doors:

In addition to the steps above, the following steps are required to meet the specific requirements for the installation of fire doors. After stage 5, the gap between the wall and the door lining requires filling with fire retardant cavity foam. Once the frames have been painted the intumescent seals can be fitted.